



Pulsarlube BT App [General Guidance]

Getting Started

Pulsarlube BT App & Server admin access is available after signing up in the App. The admin must create secondary user accounts at <https://bt.pulsarlube.com> in order for accounts to have shared access to the same lubricators.

**Lubricator access cannot be shared between multiple admin accounts created via the App.*

- To sign up, open the App and tap **Sign up**.
- To log in, enter email address and password. Then select either **General [Manage BT]** or **Registration [Register BT]** to start. Lubricators will need to be registered in **Registration** before being able to manage them in **General**.
- **General [Manage BT]** – *to control, check, or modify settings of registered lubricators*
 - Only accounts with General access can control, check, and modify settings of registered lubricators.
 - You are unable to register or unregister lubricators in General.
- **Registration [Register BT]** – *to pair unregistered lubricators to the account*
 - Only accounts with Registration access can pair and unpair lubricators.
 - You are unable to control, check, or modify any lubricator settings in Registration.



Admin accounts will automatically have access to both **General** and **Registration**. When creating secondary accounts, admins can limit secondary account access to either **General** or **Registration**, or grant access to both.


Pulsarlube BT App [General Guidance]

Settings

Settings	
test11 test11@pulsarlube.com	
Data backup	
Backup data	Back up lubricator data as either a csv or text file when the person in charge of the lubricator changes.
Customer Service	
Customer Service	Inquire and check answer
Settings	
Lubricator update notification settings 5day(s)	When there has been no update since last synchronization within a preset number of days (ex. 5 days), a push notification pops up.
Notice	
Version	
Pulsarlube BT manual	Pulsarlube BT Lubricator User Manual
Pulsarlube BT App manual	Pulsarlube BT App User Manua
Change language	Change Language (English, Korean, German, Spanish, Japanese, Chinese, French)
Logout	Sign out


Pulsarlube BT App [Registration Access]

Layout & Features



Register Lubricators


- Select lubricators and tap **Register**. If lubricators are not showing up in the App, make sure a battery pack is installed in BT lubricator(s) and tap **Rescan**.



Pulsarlube BT App [Registration Access]


Unregister Lubricators

- Swipe left to delete
- Tap **Confirm** on pop-up menu



Exit from Registration Mode

- Tap **Logout**
- Tap **Yes** on pop-up menu



Pulsarlube BT App [General Access]

Layout & Features

Rescan

Add Group (Add / Move)

Renamed Lubricator

Remaining Grease

Green : 70% ~ 100%

Yellow : 30% ~ 69%

Red : Below 29%

Settings

Deselect All

View Lubricator Details

Warning
(Dispensing completion, excessive backpressure, low battery, lubricator update overdue)

Select / Deselect Lubricator

Yellow : Selected

White : Deselected

Default Lubricator ID

Greyed Lubricator :
Lubricator out of Bluetooth range / Network Error

Group Name

Select / Deselect Group

Green : Selected

Black : Deselected

Rename



Lock (Password required to access, in order to prevent accidental changing of settings or tampering)

Hide or view the lubricators in the group

Pulsarlube BT App [General Access_Naming Lubricators]




Set Lubricator Name

- Select lubricator ID and tap **Rename**



Change Lubricator Name


- Swipe left and select **Rename**




Pulsarlube BT App [General Access_Managing Lubricators]

Check Lubricator Status

- Tap the arrow icon to see lubricator status and details




- Tap BT lubricator operation settings to manage settings



Pulsarlube BT App [General Access_Grouping Lubricators]

Create Groups

- Tap **+Add Group**. Create a password to prevent unauthorized access.



Pulsarlube BT

Enter a group name

Enter a group name


Enter password

Password (4 digits)

Password re-type (4 digits)

Cancel
Confirm


- If the password is not entered for creation of a group, the group lock is unavailable so the lock icon does not appear. The lubricator status and details are also shared among customer employees.



Pulsarlube BT App [General Access_Grouping Lubricators]

Add Lubricators to Existing Groups

- Select lubricators, select group, then tap **+Add Group**.



* **Note** : Only lubricators in range can be added to groups.

(Black : in range / Greyed out : out of range)

Edit Group Settings

- Press and hold group name for 3 seconds. Group settings can be modified only by authorized users after entering password. Admin accounts can change and control group functions without a password.

